


|   |      |           |         |  |                                    |  |  |  |
|---|------|-----------|---------|--|------------------------------------|--|--|--|
| UNLESS OTHERWISE SPECIFIED:<br>DIMENSIONS ARE IN MILLIMETERS<br>SURFACE FINISH:<br>TOLERANCES:<br>LINEAR:<br>ANGULAR: |      |           | FINISH: |  | DEBURR AND<br>BREAK SHARP<br>EDGES |  | <br>TITLE:<br>Birger Canon EF Adapter<br>for AVT GX3300 Camera<br>Uncontrolled: 20 October 2017 |  |
| DRAWN   | NAME | SIGNATURE | DATE    |  |                                    |  |  |  |
| CHK'D   |      |           |         |  |                                    |  |  |  |
| APPV'D  |      |           |         |  |                                    |  |  |  |
| MFG   |      |           |         |  |                                    |  |  |  |
| Q.A   |      |           |         |  | MATERIAL:                          |  | DWG NO.  |  |
|   |      |           |         |  |                                    |  | rd-ef1-ag1-x   |  |
|   |      |           |         |  | WEIGHT:                            |  | SCALE:1:1  |  |
|   |      |           |         |  |                                    |  | SHEET 1 OF 1   |  |

A3